

FusionPBX

Configuration Sip Trunk

1. Dans Accounts > Gateways: rajouter un compte

Gateway

Defines a connections to a SIP Provider or another SIP server.

Gateway	<input type="text" value="OVH"/> <small>Enter the gateway name here.</small>
Username	<input type="text" value="0032"/> <small>Enter the username here.</small>
Password	<input type="password" value="....."/> <small>Enter the password here.</small>
From User	<input type="text"/> <small>Enter the from-user here.</small>
From Domain	<input type="text"/> <small>Enter the from-domain here.</small>
Proxy	<input type="text" value="sip5.ovh.be"/> <small>Enter the hostname or IP address of the proxy. host[:port]</small>
Realm	<input type="text" value="sip5.ovh.be"/> <small>Enter the realm here.</small>
Expire Seconds	<input type="text" value="1800"/> <small>Enter the expire-seconds here.</small>
Register	<input checked="" type="checkbox" value="True"/> <small>Choose whether to register.</small>
Retry Seconds	<input type="text" value="30"/> <small>Enter the retry-seconds here.</small>
⚙️ ADVANCED	
Context	<input type="text" value="public"/> <small>Enter the context here.</small>
Profile	<input type="text" value="external"/> <small>Enter the profile here.</small>

2. Dans Advanced > Access control: rajouter l'IP Wan du serveur SIP Trunk dans la règle Providers

Access Control

Access control list can allow or deny ranges of IP addresses.

Name	<input type="text" value="providers"/>	Enter the name.												
Default	<input type="button" value="deny"/>	Select the default type.												
Nodes	<table border="1"><thead><tr><th>Type</th><th>CIDR</th><th>Description</th><th>Action</th></tr></thead><tbody><tr><td><input type="button" value="allow"/></td><td><input type="text" value="91.121.129.133/32"/></td><td><input type="text" value="OVH"/></td><td><input type="checkbox"/></td></tr><tr><td><input type="button" value=""/></td><td><input type="text"/></td><td><input type="text"/></td><td><input type="checkbox"/></td></tr></tbody></table>	Type	CIDR	Description	Action	<input type="button" value="allow"/>	<input type="text" value="91.121.129.133/32"/>	<input type="text" value="OVH"/>	<input type="checkbox"/>	<input type="button" value=""/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	Enter the description.
Type	CIDR	Description	Action											
<input type="button" value="allow"/>	<input type="text" value="91.121.129.133/32"/>	<input type="text" value="OVH"/>	<input type="checkbox"/>											
<input type="button" value=""/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>											
Description	<input type="text"/>	Enter the description												

3. Dans Status > Sip Status: Relancer les ACL

4. Dans Dialplan > Destination: Ajouter une règle pour le numéro entrant

Destination

Inbound destinations are the DID/DDI, DNIS or Alias for inbound calls.

Type	<input type="button" value="Inbound"/>	Select the type.
Country Code	<input type="text"/>	Enter the country code.
Destination	<input type="text" value="003:"/>	Enter the destination.
Caller ID Name	<input type="text"/>	Enter the caller ID name.
Caller ID Number	<input type="text"/>	Enter the caller ID number.
Context	<input type="text" value="public"/>	Enter the context.
Conditions	<input type="text"/> <input type="text"/>	If the condition matches perform the action.
Actions	<input type="button" value="3000 AppelEntrant"/> <input type="button" value=""/>	Add additional actions.
User	<input type="text"/>	Assign this destination to a user.

Autoprovision

Snom

1. Dans l'interface du téléphone, choisir Advanced, QOS/Security et introduire le "http client" user et password qui correspond au http_auth_username et http_auth_password que vous avez défini

dans les default settings de Fusion Pbx

The screenshot shows the FusionPBX configuration interface. On the left is a navigation menu with sections: Operation (Home, Directory), Setup (Preferences, Speed Dial, Function Keys, Identity 1-12, Action URI Settings, Advanced, Certificates, Software Update), and Status (System Information, Log, SIP Trace, DNS Cache, Subscriptions, PCAP Trace, Memory, Settings, Manual). The 'Advanced' menu item is highlighted with a red box and a '1' in a red circle. The main content area has tabs: Network, Behavior, Audio, SIP/RTP, QoS/Security (highlighted with a red box and a '2' in a red circle), and Update. The QoS/Security page is divided into sections: Quality of Service (RTP and SIP Type of Service), VLAN (VLAN Id and Priority), PC Port (VLAN Id and Priority), IEEE 802.1X Authentication (Off), Security (Ignore Security Advises, Use Hidden Tags, Restrict URI Queries, Allow CSTA Control, Empty Client Cert, Filter Packets from Registrar, Authentication for SIP Reboot and Check-Sync, Administrator Mode, Administrator Password, Minimum PIN Length, Maximum PIN Retries), HTTP Server (User: admin, Password, Authentication Scheme: Digest), and HTTP Client (User: phone_mgmt, Password). The 'HTTP Client' section is highlighted with a red box and a '3' in a red circle.

2. Ensuite dans l'onglet Update, introduire l'url de provisioning exemple <https://192.168.103.30/app/provision/index.php?mac={mac}> et faire Apply

3. Après un redémarrage, un problème de certificat apparaîtra. Cliquez dans le menu certificates → unknown certificates et acceptez l'exception

Certificates



From: <https://wiki.makeitsimple.be/> - makeITsimple wiki

Permanent link: <https://wiki.makeitsimple.be/doku.php?id=linux:fusionpbx&rev=1716557152>

Last update: 2024/05/24 13:25

